

## CLAVINOVA CLP

	CLP-725	CLP-735	CLP-745	CLP-775	CLP-785
<b>N. TASTI</b>	88	88	88	88	88
<b>TIPO TASTIERA</b>	GrandTouch-S™ keyboard: synthetic ebony and ivory keytops, escapement	GrandTouch-S™ keyboard: synthetic ebony and ivory keytops, escapement	GrandTouch-S™ keyboard: wooden keys (white only), synthetic ebony and ivory keytops, escapement	GrandTouch™ keyboard: wooden keys (white only), synthetic ebony and ivory keytops, escapement	GrandTouch™ keyboard: wooden keys (white only), synthetic ebony and ivory keytops, escapement
<b>88 KEY LINEAR GRADED HAMMER</b>	NO	NO	NO	YES	YES
<b>CONTRAPPESI</b>	NO	NO	NO	NO	YES
<b>N. PEDALI</b>	3	3	3	3	3
<b>HALF PEDAL</b>	YES	YES	YES	YES	YES
<b>FUNZIONI PEDALI</b>	Damper/Sostenuto/Soft	Damper/Sostenuto/Soft Altre funzioni assegnabili	Damper/Sostenuto/Soft Altre funzioni assegnabili	Damper/Sostenuto/Soft GP RESPONSE PEDAL. Altre funzioni assegnabili	Damper/Sostenuto/Soft GP RESPONSE PEDAL. Altre funzioni assegnabili
<b>DISPLAY</b>	NO	FULL DOTS LCD 128 X 64	FULL DOTS LCD 128 X 64	FULL DOTS LCD 128 X 64	FULL DOTS LCD 128 X 64

<b>PANNELLO COMANDI</b>	PULSANTI	PULSANTI	PULSANTI	TOUCH SENSOR	TOUCH SENSOR
<b>PIANO SOUND</b>	YAMAHA CFX - BÖSENDORFER IMPERIAL	YAMAHA CFX - BÖSENDORFER IMPERIAL	YAMAHA CFX - BÖSENDORFER IMPERIAL	YAMAHA CFX - BÖSENDORFER IMPERIAL	YAMAHA CFX - BÖSENDORFER IMPERIAL
<b>CAMPIONE BINAURALE</b>	CFX	CFX-BÖSENDORFER	CFX-BÖSENDORFER	CFX-BÖSENDORFER	CFX-BÖSENDORFER
<b>KEY-OFF</b>	YES	YES	YES	YES	YES
<b>SMOOTH RELEASE</b>	YES	YES	YES	YES	YES
<b>VRM</b>	YES	YES	YES	YES	YES
<b>GRAND EXPRESSION MODELING</b>	YES	YES	YES	YES	YES
<b>POLIFONIA</b>	256	256	256	256	256
<b>N. VOICE</b>	10	38	38	38	53 + 14 DRUM/SFX KITS + 480 XG VOICES
<b>RITMI</b>	NO	20	20	20	20
<b>PIANO ROOM</b>	NO	YES	YES	YES	YES
<b>REVERB</b>	4	6	6	6	6
<b>CHORUS</b>	NO	3	3	3	3
<b>BRILLIANCE</b>	NO	7 + USER	7 + USER	7 + USER	7 + USER
<b>INTELLIGENT ACOUSTIC CONTROL</b>	YES	YES	YES	YES	YES
<b>STEREOPH. OPTIMIZER</b>	YES	YES	YES	YES	YES
<b>MASTER EFFECT</b>	NO	12	12	12	12
<b>SPLIT</b>	NO	YES	YES	YES	YES
<b>DUAL/LAYERS</b>	YES	YES	YES	YES	YES

<b>DUO</b>	YES	YES	YES	YES	YES
<b>N. PRESET SONG</b>	10 Voice Demo Songs, 50 Classics	21 Voice Demo Songs, 50 Classics+303 LESSONS	21 Voice Demo Songs, 50 Classics+303 LESSONS	21 Voice Demo Songs, 50 Classics+303 LESSONS	25 Voice Demo Songs, 50 Classics+303 LESSONS
<b>REC SONG MIDI</b>	1 SONG - 2 TRACCE	250 SONG - 16 TRACCE	250 SONG - 16 TRACCE	250 SONG - 16 TRACCE	250 SONG - 16 TRACCE
<b>USB AUDIO PLAY/REC</b>	NO	WAV	WAV	WAV	WAV
<b>SCALE TYPE</b>	NO	7 TYPES	7 TYPES	7 TYPES	7 TYPES
<b>BLUETOOTH</b>	NO	NO	AUDIO/MIDI	AUDIO/MIDI	AUDIO/MIDI
<b>METRONOMO</b>	YES	YES	YES	YES	YES
<b>TRANSPOSE</b>	YES	YES	YES	YES	YES
<b>HEADPHONES</b>	Standard stereo phone jack x 2	Standard stereo phone jack x 2	Standard stereo phone jack x 2	Standard stereo phone jack x 2	Standard stereo phone jack x 2
<b>MIDI</b>	NO	IN-OUT-THRU	IN-OUT-THRU	IN-OUT-THRU	IN-OUT-THRU
<b>AUX IN</b>	NO	STEREO MINI	STEREO MINI	STEREO MINI	STEREO MINI
<b>AUX OUT</b>	NO	[L/L+R] [R]	[L/L+R] [R]	[L/L+R] [R]	[L/L+R] [R]
<b>AUX PEDAL</b>	NO	NO	NO	NO	YES
<b>USB TO DEVICE</b>	NO	YES	YES	YES	YES
<b>USB TO HOST</b>	YES	YES	YES	YES	YES
<b>IMPIANTO AUDIO</b>	20 W X 2	30 W X 2	(50 W + 50 W) X 2	(42 W + 50 W + 50W) X 2	(50 W + 50 W + 50W) X 2
<b>APP</b>	SMART PIANIST	SMART PIANIST	SMART PIANIST	SMART PIANIST	SMART PIANIST